Hako Scrubmaster B120 R





- 1. Disconnect mains plug of the charger and put it in front of the seat 1.
- 2. Open soiled water tank lid 2 and lock the lids latch 3. Fill the clear water tank from opening 4. Control the filling level by the filling level indication 5. (Located next to suction hose)
- 3. Switch the machine on by the key switch 6. Actuate drive direction from button 7.
- 4. Press green button 8 to lower brush head 9 and squeegee 10, suction turbine switches on.
- 5. Press pedal 11, machine moves and brush head drive switches on. Use button 12 to adjust the water (if necessary)

NOTE! Make sure that pads / brushes are installed!!!

Qualified persons only are authorised to operate the machine!

The machine is not designed for coarse material! Floor area sweeping before! Use only cleaning agents suitable for automatic machines! (low foaming!)

Please pay attention to the informations in the instruction manual!

Hako Scrubmaster B120R





Daily maintenance:

- ➤ Empty clear water tank by opening the clear water filter covering 1. (red water shut off valve 2 must be open)
- ➤ Empty soiled water tank from hose 3 and clean soiled water tank 4.
- ➤ Check suction filter 5 and lid sealing 6, clean if required.
- Remove suction hose 7 and clean it
- ➤ Remove squeegee 8 and clean it, check sealing strips
- ➤ Lift up the wiper 9 from the handle and swing it to the side. Remove brushes/pads pressing pedals 10 and clean them. Check brushes / pads for wearing
- Clean wipers 9 left and right sealing strips
- Charge battery

Weekly maintenance:

- ➤ Check and clean brush head and wipers sealing strips 9 and turn or replace them if necessary
- Clean the machine from outside
- Check and clean clear water filter 1
- ➤ Clear water tank thorough emptying / maintenance from opening 11
- ➤ Check squeegees sealing strips 8 and turn or replace them if necessary

Suction result is bad:

- suction filter 5, suction hose 7 or squeegee 8
 is blocked.
- Locking cap of the soiled water drain hose 3 is open.
- Tank lid sealing 6 of the soiled water tank is defect.

Turn off the machine before maintenance!

Please pay attention to the informations in the instruction manual, you can find manual by reading QR-code.

