

Hako Sweepmaster B500



Operation



1. Disconnect mains plug of the charger from outlet and place it to it's box **1**.
2. Switch on the machine by switch **2**.
3. Lower side brush from lever **3** if needed or take power of from the side brush by switch **4**.
4. Pull the bail **5** to the handle. Brush(es) starts.



Maintenance

➤ Clean the filter using the shaking device **6**. If the filter is very dirty, take the filter holder of opening the wing bolts **7** and clean the filter with vacuum cleaner or dropping it evenly to the floor few times dirty side facing down. Empty container **8** by lifting containers lock **9** up and pulling the container out.

➤ Charge battery



Qualified persons only are authorised to operate the machine!

Not recommended to use on wet surfaces!

Refer to the operating instructions for further details on proper use!